



1.) Plug in the E-tank using the supplied mini-USB cable.

2.) Place the E-tank next to Mega Man's LEFT LEG to illuminate his Buster Gun and Ear Pods.

The side of the E-tank opposite of the plug **MUST** be placed next to Mega Man's **LEFT** leg in order for the induction process to work, as shown in the image on the left.

1-2 minutes of charge time might be needed in order for Mega Man to illuminate properly.



NOTE: Mega Man will not illuminate if the E-tank is placed in any other location other than specified (see below).

